





## Laying Membrane

Step by step guide on laying our Techno EDPM Membrane to your next rubber roofing project.

|   |   |
|---|---|
|    | <p><b>Step 1</b></p> <p>Ensure deck is dry and clean.</p>   |
|   | <p><b>Step 2</b></p> <p>Position membrane on the roof and allow to relax for 30-45 minutes, slightly longer in colder temperatures.</p>   |
|  | <p><b>Step 3</b></p> <p>Fold back one half of the rubber and apply an even coat of water-based adhesive to the deck using roller and sleeve. For best results, it is essential that the water based deck adhesive is thoroughly stirred with a paddle stirrer prior to use.</p> |
|  | <p><b>Step 4</b></p> <p>Mate the rubber to the adhesive immediately and use a soft broom to sweep out any air bubbles.</p>  |

**Step 5**

Repeat the process for the other side.

**Step 6**

Thoroughly sweep roof.