





Onto Tiles

A guide to installing Lineflex Fleece Backed EPDM membrane onto tiles.

 <p>A 150mm</p>	<p>Step 1 Allow 150mm overhang onto tiles.</p>
	<p>Step 2 Dress lead into place 6" onto tiles, 3" onto the deck. We recommend using minimum 9" Code 4 lead cut into 1200mm lengths max.</p>
	<p>Step 3 Fix into position using screws.</p>
	<p>Step 4 Apply Quick Prime plus to lead and rubber approx. 160mm wide using QuickScrubber pad and handle. Allow to go touch dry.</p>



Step 5

Centralize the 6" batten cover strip and carefully remove release paper applying downward pressure. Use a silicone roller to seal.