

Under Tiles

Step by step guide on installing our Techno EPDM membrane under tiles/sales for your next rubber roofing project.

 A 3D perspective diagram showing a roof section. On the right, several orange tiles are being lifted by a wooden batten. On the left, a grey EPDM membrane is already installed over a white substrate. Arrows indicate the direction of removal.	<p>Step 1 Carefully remove tiles and battens and place to one side.</p>
 A 3D perspective diagram showing the roof section. The orange tiles have been removed, and a black felt underlay is being folded up and tucked under the grey EPDM membrane. A curved arrow indicates the folding motion.	<p>Step 2 Fold the felt underlay up and tuck under existing tiles.</p>
 A 3D perspective diagram showing the roof section. A green contact adhesive is being applied to the grey EPDM membrane. A small white bottle of adhesive is shown on the left. The black felt underlay is still folded up on the right.	<p>Step 3 Apply a thin coat of contact adhesive to the rubber membrane and lay board. Shop EPDM Adhesives</p>
 A 3D perspective diagram showing the roof section. The black felt underlay is being folded down and mated to the grey EPDM membrane. A curved arrow indicates the folding motion.	<p>Step 4 Allow both surfaces to dry and, starting from the bottom, mate together, working the rubber into any angle changes.</p>

**Step 5**

Reinstate the felt underlay and battens over the rubber.

**Step 6**

Reinstall the tiles.