


Internal Corner

Step by step guide on installing an internal corner to your next rubber roofing project.

	<p>Step 1 Adhere one of the upstands and apply contact adhesive to the remaining rubber and upstand as shown. Draw a 45-degree line from the corner outwards. Shop EPDM Adhesives</p>
	<p>Step 2 Once dry, mate the EPDM as shown, up to the line. Fold the remaining section of rubber to form a neat triangular flap that will neatly dress into the internal corner. Shop EPDM Membranes</p>
	<p>Step 3 Apply primer with a quick scrubber pad and handle, allow to dry.</p>
	<p>Step 4 Mate the surfaces together and roller.</p>