




Internal Corner

Step by step guide on installing an internal corner to your next rubber roofing project.

 An isometric diagram showing a corner formed by two brick walls. A green EPDM membrane is partially installed on the floor. A white adhesive dispenser is shown applying adhesive to the corner and the remaining rubber sheet. A faint 45-degree line is visible on the floor.	<p>Step 1</p> <p>Adhere one of the upstands and apply contact adhesive to the remaining rubber and upstand as shown. Draw a 45-degree line from the corner outwards.</p> <p>Shop EPDM Adhesives</p>
 An isometric diagram showing the EPDM membrane being folded into a neat triangular flap at the corner. A 45-degree line is clearly marked on the floor, extending from the corner.	<p>Step 2</p> <p>Once dry, mate the EPDM as shown, up to the line. Fold the remaining section of rubber to form a neat triangular flap that will neatly dress into the internal corner.</p> <p>Shop EPDM Membranes</p>
 An isometric diagram showing a white bucket of primer and a black scrubber pad being used to apply primer to the corner and the remaining rubber sheet. The triangular flap is already in place.	<p>Step 3</p> <p>Apply primer with a quick scrubber pad and handle, allow to dry.</p>
 An isometric diagram showing a roller being used to press the EPDM membrane into the corner, ensuring a tight seal between the two walls.	<p>Step 4</p> <p>Mate the surfaces together and roller.</p>