






Wall Trim Flashing

A guide to installing a wall trim flashing.

 <p>The diagram shows a brick wall with a grey rubber strip being applied to its surface. A brush is used to clean the wall and the rubber. A circular inset shows a close-up of a 'Cut chase in brickwork'.</p>	<p>Step 1 Thoroughly clean the wall, chase and rubber.</p>
 <p>The diagram shows a green contact adhesive being applied to the back of the grey rubber strip and the brick wall.</p>	<p>Step 2 Apply a thin coat of contact adhesive to the rubber and the wall.</p>
 <p>The diagram shows the grey rubber strip being pressed against the brick wall, with a silicone roller being used to smooth the joint.</p>	<p>Step 3 Once touch dry, starting at the bottom, carefully mate the surfaces together. Smooth by hand and silicone roller.</p>
 <p>The diagram shows the grey rubber strip being trimmed with a utility knife to fit the wall.</p>	<p>Step 4 Trim membrane.</p>




Step 5

Position a piece of 9" QuickSeam Formflash or a Detail Kit as shown and mark the perimeter, allowing an extra 1cm.




Step 6

Apply Quick Prime plus to the marked area using a Quick Scrubber pad and handle, allow primer to dry.



Step 7

Peel back a section of backing paper and starting from the top, slowly work downwards as shown.





Step 8

Apply a gentle heat source to the corner if needed.




Step 9

Thoroughly roller with Silicone and Penny Rollers.



Step 10

Insert wall trim into chase and secure at 600mm centres with the supplied fixings. Raw plugs are not needed if a 5.5mm masonry drill bit is used.



Step 11

Thoroughly seal chase with Wall Mastic.