











# Wall Trim Flashing


Step by step guide on installing wall-trim flashing to your next EPDM Roofing project.

 <p>The diagram shows a cross-section of a roof edge where a blue EPDM membrane meets a brick wall. A circular inset shows a close-up of a 'Cut chase in brickwork' where a channel has been cut into the brick. A broom is shown sweeping the brick wall, and a brush is shown cleaning the blue rubber membrane.</p>	<p><b>Step 1</b> Thoroughly clean the wall, chase and rubber.</p>
 <p>The diagram shows the same roof edge. A green layer of contact adhesive is now applied to the brick wall and the blue rubber membrane. A white adhesive bottle is shown on the roof surface.</p>	<p><b>Step 2</b> Apply a thin coat of contact adhesive to the rubber and the wall . <a href="#">Shop EPDM Adhesives</a></p>
 <p>The diagram shows the blue rubber membrane being pressed against the green adhesive on the brick wall. The membrane is shown partially adhered to the wall.</p>	<p><b>Step 3</b> Once touch dry, starting at the bottom, carefully mate the surfaces together. Smooth by hand and silicone roller.</p>
 <p>The diagram shows the blue rubber membrane fully adhered to the brick wall. A hand is shown using a tool to trim the excess membrane from the edge of the wall.</p>	<p><b>Step 4</b> Trim membrane.</p>

	<p><b>Step 5</b></p> <p>Position a piece of 9" Formflash or a Detail Kit as shown and mark the perimeter, allowing an extra 1 cm.</p> <p><a href="#">Shop Flashings &amp; Seam Tapes</a></p>
	<p><b>Step 6</b></p> <p>Apply Techno primer to the marked area using a Scrubber pad and handle, allow primer to dry.</p>
	<p><b>Step 7</b></p> <p>Peel back a section of backing paper and, starting from the top, slowly work downwards as shown.</p>
	<p><b>Step 8</b></p> <p>Apply a gentle heat source to the corner if needed.</p>
	<p><b>Step 9</b></p> <p>Thoroughly roller with Silicone and Penny Rollers.</p>

**Step 10**

Insert wall trim into chase and secure at 600mm centres with the supplied fixings. Rawplugs are not needed if a 5.5mm masonry drill bit is used.

**Step 11**

Thoroughly seal chase with Wall Mastic.